



SEN-0002 INSTALL

READ THESE INSTRUCTIONS BEFORE YOU BEGIN INSTALLATION

INSTALLATION

The **iAIRE** CO2 sensor is a versatile product and can be mounted to any standard wall. It is designed for real-time CO2 detection in basic HVAC and Ventilation systems.

MOUNTING


Find a suitable location on the wall to mount the sensor. The sensor should be mounted at a similar height to the thermostat.

⚠ (It is recommended when mounting on a wall to secure the unit using drywall anchors or to wall studs directly.)

Using screws, mount the sensor to the wall ensuring it is secure.

(Unit should be mounted vertically so that product labels are facing up)

(hole for wall mounting located on back of device)



WIRING

⚠ (Be sure to follow all local and electrical codes. Turn off power to the unit before mounting or making any connections.)

- Only 0~10VDC output

