Submittal

Powered and non-powered convenience outlets

Part Number

ITEM	PART #
Service Outlet (non-powered)	OPT-UE-NONPWR-OUTLET-INSTALL

Description

Installs a 20 amp, non-powered convience outlet on a customer provided HVAC unit.

Part Number

ITEM	PART #
Service Outlet (powered)	OPT-UE-PWROUTLET-INSTALL

Description

Installs a 15 amp, powered convience outlet on a customer provided HVAC unit.

Powered Outlet Wiring Diagram