



Thread the ion brush wires through the wire reliefs and tighten until they are secured. Push the wire strain reliefs into the emitter bracket.

The ion brush tips should be about 3 3/4" (~9cm) away from the side of the duct inside surface. Also, keep the carbon fiber brush tips far enough away from any conductive surface to prevent arcing.



(Be sure to follow all local and electrical codes. Turn off power to the unit before mounting or making any connections.)

Part Number

ION - □A * 00□

VOLTAGE:

- A - 24VAC / VDC, 1
- G - 208/230VAC, 1



- Verify the product will not overload the power requirement for the electrical system before wiring.
- - o 35" (~90cm) red positive wire
 - o 35" (~90cm) black negative wire

- Unit should be interlocked to a fan operation and only run with the fan is on.
- The green LED on the block will illuminate when powered and operating.
- Route and secure all wiring properly.

